



## Section V OPERATION LIMITATIONS

### PURPOSE.

This section includes limitations for the aircraft, engine and auxiliary flight equipment for normal operation. These limitations must be observed at all times to prevent possible damage to equipment through excessive loads. Particular attention must be given to the instrument marking pages in this section, as this data is not repeated elsewhere in the text. For complete restrictions, carefully read this entire section including the instrument marking page.

You would do well to study this section until it is memorized; however, it is not recommended that you rely on memory alone for the limitations of the aircraft.

### MINIMUM CREW.

While there is a provision for both a pilot and copilot, the airplane may be flown easily and safely by one pilot under any conditions. The minimum crew, therefore, will be a pilot in the left seat. Additional crew members as required will be added at the direction of the Commanding Officer.

### ENGINE LIMITATIONS.

The engine limitations as set up by the instrument markings are based on grade 91/96 fuel. Should grade 91/96 fuel not be available, the next higher grade may be used with the same limitations. Grade 87 fuel may be used if no other is available.

In the event an engine overspeeds, any speed in excess of 2900 rpm requires that the engine be inspected. A speed of 3000 rpm necessitates removal of the engine. In either event, the degree of overspeed, the length of time the engine operated at that speed and, if possible, the cause, should be noted and reported.

### ELECTRICAL SYSTEM.

Do not operate landing gear and flaps simultaneously, or with landing lights on. Such operations will considerably overload the electrical system. Refer to Section VII for power requirements.

### LANDING LIGHTS.

The landing lights shall not be extended at speeds in excess of 110 mph IAS (95 knots). Extension at greater speeds can cause structural failure in the light mechanism.

### PROHIBITED MANEUVERS.

All acrobatic maneuvers, including spins, are prohibited. However, should an accidental spin occur, follow normal spin recovery procedure, detailed in Section VI.

### WEIGHT AND BALANCE LIMITATIONS.

The lavatory compartment is restricted against occupancy during take-off and landing.


The forward CG limit of the aircraft is 107 inches, the rear limit 118.8 inches.







### OPERATING WEIGHT LIMITATIONS.


In flight planning, the pilot is often confronted with this question: "What is the maximum weight at which this aircraft may be operated?" Due to certain weight controlling criteria, there is no single answer to this question. Since these criteria can be set at various optimums to accommodate varying conditions, it becomes apparent that the maximum weight of an aircraft is a varying quantity. Following are some of the controlling criteria with illustrations of how they can vary.

# INSTRUMENT MARKINGS


FUEL GRADE 91/96




ENGINE GAGE UNIT			
OIL TEMP		OIL PRESS	
	40° C	50 PSI	MINIMUM
	60° TO 75° C	70 TO 90 PSI	NORMAL
	85° C	100 PSI	MAXIMUM
FUEL PRESS			
	3 PSI MIN FOR FLIGHT		
	3 TO 4 PSI NORMAL		
	6 PSI MAXIMUM		



CYLINDER HEAD TEMP	
	150° TO 232° C NORMAL
	260° C MAXIMUM DURING TAKE-OFF



AIRSPEED INDICATOR	
MPH	
	117 MAXIMUM FOR FLAPS (LANDING GEAR 125)
	253 MAXIMUM ALLOWABLE (STILL AIR)




CARB MIXTURE TEMP	
	- 10° TO + 3° C ICING ZONE
	3° TO 20° C NORMAL
	20° C DANGER OF DETONATION

CDC-1-54A

Figure 5-1. (Sheet 1 of 2)


FUEL GRADE 91/96



**MANIFOLD PRESSURE (DUAL)**  
INCHES HG

18 TO 37


FULL RICH REQUIRED  
37 TAKE-OFF



**TACHOMETER (DUAL)**  
RPM


1700 TO 2200

FULL RICH REQUIRED  
2300 TAKE-OFF  
MAXIMUM CONTINUOUS



**DEICING PRESSURE**

6 TO 8.5 PSI NORMAL  
10 PSI MAXIMUM



**SUCTION GAGE**

3.75 IN HG MINIMUM  
3.75 TO 4.25 IN HG NORMAL  
4.25 IN HG MAXIMUM

Figure 1-5. (Sheet 2 of 2)

**OPERATING WEIGHT.**

The weight limitations chart for the aircraft is based on an operating weight of 6520 pounds. This is an approximate weight including the aircraft (basic weight) with standard crew and full oil. Since individual airplane basic weights vary, it will be necessary to adjust the chart for specific aircraft. The intersection of the cargo (ordinate) with wing fuel (abscissa) at "0" represents the airplane operating weight of 6520 pounds.

**GROSS WEIGHT.**

Diagonal lines on the chart indicate the gross weights of the loaded aircraft.

**DISTRIBUTION OF LOAD.**

The maximum load that an aircraft can carry is dependent on the way that load is distributed throughout the aircraft. Since the wings support the weight of an aircraft in flight, the greater the load carried in the fuselage, the greater will be the bending moment on the wings. This means that an aircraft might safely carry 10,000 pounds if 6000 pounds were carried in the fuselage and 4000 pounds were in the wings. The same 10,000 pounds might become an unsafe load if 8000 pounds were carried in the fuselage and 2000 pounds in the wings. The unsafe condition would result from the excessive bending moment imposed on the wings by the 8000 pounds in the fuselage. It is to be noted that this is merely an example and does not apply to this aircraft.

**SPACE CAPACITY.**

The space available may limit the load that can be carried in an aircraft. This does not normally apply to cargo aircraft.


**MARGIN OF SAFETY AND LOAD FACTORS.**

Ability to withstand shocks or additional loads resulting from maneuvers becomes increasingly less,

as the aircraft structure is loaded to higher weights. The amount of shock or additional load that the structure will sustain before failure occurs is the margin of safety. In planning a mission, it must be understood that the "maximum" permissible weight may depend on the margin of safety desired for the various supporting structures (wings, landing gear, etc.). Should the mission require excessive maneuvering or flight through turbulent air, it would be advisable to maintain a greater margin of safety for the wing structure and, as pointed out, the greater the margin of safety, the lower the "maximum" permissible weight. Regarding aircraft, load factors are used as an indication of the margin of safety available. The structural margin of safety of the wing, for example, will be equal to the difference between the load factor the wing is capable of making good and the load factor the wing is sustaining at that moment. Example: Should the aircraft be loaded so that the wing is capable of making good a load factor of 2.6 and during the flight, load factors of 2.0, 2.3 and 1.5 are imposed on the wing, the margins of safety during these phases of flight will be 0.6, 0.3 and 1.1 load factors, respectively. The above shows how important it is to anticipate the maximum load factors that will be encountered during a mission, so that the aircraft will be loaded such that the load factors it can make good will never be exceeded during any part of the flight. Experience has shown that it is difficult to accomplish a mission, even under ideal conditions, during which the aircraft will not be subjected to load factors of at least 2.0.


**WING LIMITATIONS.**

Lines showing wing strength in terms of aircraft load factors for combinations of fuel and payload are shown for 2.0g, 2.5g and 3.36g. The 3.36g is the load which the aircraft structure will sustain at the de-



CDC-1-85

# WEIGHT LIMITATIONS



## WEIGHT LIMITATIONS CHART

- 6520 LB Operating Weight
- 9000 LB Design Landing Gross Weight at 10 FPS Contact Sinking Speed — Landing Load Factor = 3.0 Flight Load Factor 3.36
- 9200 LB 100 FPM Rate of Climb — Sea Level — Hot Day One Engine Inoperative — Prop Feathered Take-Off Power 450 BHP — Gear and Flaps Up
- 9680 LB 100 FPM Rate of Climb — Sea Level — Standard Day One Engine Inoperative — Prop Feathered Take-Off Power 450 BHP — Gear and Flaps Up
- 9800 LB Design Gross Weight for Take Off, Landing, and Flight for 2.5 g's Maneuver Load Factor. Tail Wheel and Tire become Critical above this Weight because there is a possibility of the Tire and Tube blowing out upon Rough Landings, or Taxiing over Extremely Rough Ground.
- 10360 LB Maximum Fuel and Maximum Body Weight Based on Compartment Loading Limitations — See Chart "E" T.O. 01-90CDB-5 Flight Load Factor = 2.0
- 11960 LB Maximum Landing Gross Weight at 8 FPS Sinking Speed

Max. Cargo is the maximum load for compartments in accordance with Chart "E" of T.O. 01-90CDB-5.

NOTE: Fuel located in the fuselage is considered as cargo.

RED — NOT RECOMMENDED  
 YELLOW — CAUTIONARY  
 GREEN — RECOMMENDED

CDC-1-57

sign gross weight of 9000 pounds. Combinations of payload and fuel, for which the aircraft structure is good for less than 3.36g's, should be flown with caution, especially when making turns and pullouts. THE AIRCRAFT WILL NOT BE LOADED WITH ANY COMBINATION OF PAYLOAD AND FUEL WHICH EXTENDS BEYOND THE 2.0g LINE BECAUSE STRUCTURAL DAMAGE TO THE WING MAY OCCUR.

The wing structure is designed for landing during routine operation at a gross weight of 9000 pounds at a maximum contact sinking speed of 10 feet per second limit. Based on stress of the landing gear carry-through structures located in the wings of the aircraft, the maximum recommended landing weight is 9,800 pounds.

Figure 5-2

### LANDING GEAR LIMITATIONS.

The landing gear structure is designed for landing during routing operation at a gross weight of 9000 pounds at a maximum contact sinking speed of 10 feet per second limit. This is the maximum recommended landing weight for normal operation. The maximum recommended landing weight under emergency conditions is 9800 pounds at a landing load factor of 2.5. This weight is based upon the fact that the tail wheel and tire become critical above this weight, because there is a possibility of the tire and tube blowing out during a rough landing or when taxiing over extremely rough ground. Therefore, when landing at weights in excess of 9000 pounds, the tail down attitude should be avoided if at all possible. The maximum permissible landing gross weight is 11,960 pounds based upon a sinking speed of 8 feet per second limit.

### PERFORMANCE LIMITATIONS.

Unsatisfactory performance at higher weights may limit the maximum permissible weight of the aircraft. Maximum take-off weight must necessarily be limited by the ability of the aircraft to take-off within the available runway length, its ability to clear any obstacles and its ability to fly with partial power failure. Two performance limitations lines are shown. The explanation of the performance limits is stated in the notes which appear on the chart.

### EXPLANATION OF THE CHART.

The red area represents loadings which are not recommended. Under conditions of extreme emergency when safety of flight is of secondary importance, the Commanding Officer will determine whether the degree of risk warrants operation of the aircraft in the red zone.

The yellow area represents loadings of progressively increasing risk as the red area is approached. The structural strength becomes marginal in the landing configuration and the performance becomes marginal depending upon aircraft configuration, take-off altitude and ambient air temperature. Therefore,

adequate care must be exercised when operating in the yellow area.

The green area represents the loading conditions that present no particular problem in regard to strength or performance of the aircraft. This weight should not be exceeded unless dictated by the requirements of the mission.

### NOTE

Operating weight should never exceed that required by the mission, since unnecessary risk and equipment wear will result. The take-off weight must also be considered in light of available runways and their altitude, surrounding terrain and atmospheric temperatures.

### USE OF THE CHART.

For illustration purposes, two sample problems follow:

1. Assume that a C-45H aircraft calls for an 800 pound payload and 1000 pounds of fuel. Starting with the operating weight of 6520 pounds at "0", proceed along the vertical axis to 800 pounds; this increases the gross weight to 7320 pounds. Next proceed along the horizontal axis to 1000 pounds and project a line vertically to intersect the horizontal projection of the 800 pound line. By interpolation, the intersection will indicate a gross weight of 8,320 pounds.

2. Another example to demonstrate a problem where the operating weight of the aircraft is greater than that shown on the chart: assume an operating weight of 6720 pounds instead of 6520 pounds, or a difference of 200 pounds. Using the same requirements as in the previous example and proceeding as before, the gross weight will be found at 8320 pounds. To this value, 200 pounds must be added to correct the chart for the heavier aircraft. This increases the total gross weight to 8520 pounds.

In the event that the gross weight would fall within the red area as a result of the mission requirements, either the fuel or the cargo may be reduced to fall within the caution area.



CDC-1-58

## ALPHABETICAL INDEX

## A

Additional — Night Flight Check List	28
After Landing Procedures	36
After Take-Off Procedures	32
Aileron & Rudder Indicators	17
Air — Cold Air Controls	47
Airspeed Position Correction	82
Airspeed — Minimum Safe Single Engine	37
Air — Turbulent Air Penetration Chart	72
All Weather Operation	71-78
Analysis — Electrical Load Charts	64-67
AN/ARC-3 Command Radio	51
AN/ARC-3 Command Radio Operation	51
AN/ARN-7 Radio Compass	51
AN/ARN-7 Radio Compass Control Light	52
AN/ARN-7 Radio Compass Operation	51
Anti-icer — Carburetor	75
Anti-icing & De-icing System	48
Anti-icing — Propeller	48
— Propeller Control	48
— Propeller Operation	48
Approaches — Instrument	73
Arrangement — General Arrangement	4
Audio Switch Panels	51
Auxiliary Equipment — Description & Operation	47-54

## B

Baggage Compartment Light	52
Baggage Compartment Light Switch	52
Bail Out	44
Balance — Weight & Balance Limitations	55
Bank — Pilots Turn & Bank Power Switch	11
Bar — Master Switch	10
Battery Switches	11
Beacon Receiver	51
Marker Beacon R-122/ARN-12	51
Marker Beacon Indicators R-122/ARN-12	51
Marker Beacon Operation R-122/ARN-12	51
Before Landing Check List	33
Before Leaving Aircraft	36
Before Stopping Engines	36
Before Take-Off Check Lists	30
Booster Pumps — Fuel System Operation	63
Booster Pump Switches — Fuel	9
Booster Switch — Ignition	3
Brake — Parking Brake Handle	21
Brake System	20
Breakers — Circuit Breakers	11
Buttons — Cabin Heat	47
— Oil Bypass	6
— Propeller Feathering	3

## C

Cabin Compartment Lights —	
Lavatory & Baggage	52
Cabin Dome Light Switches	52
Cabin Door Controls	24
Cabin Heat Buttons	47
Capacity — Space	58
Case — Data	53
— Flight Report	54
— Map	54
Carburetor Anti-icing	75
Carburetor Mixture Temperature Gage	3
Characteristics — Flight	61-62
Chart — Fuel Quantity Data	13
— Main Differences Table	2
— Maximum Glide	46
— Stall	62
— Turbulent Air Penetration	72
— Use of (Weight Limitations)	60
— Weight Limitations	59
Charts — Electrical Load Analysis	64-67
Checks — Normal Procedures	25
Pre-Flight	25-30
In-Flight	31-35
Post-Flight	36
Circuit Breakers	11
Climb Curve	94C
Climb Curve — Single Engine	94D
Climb — Emergency	94L
Climb — Instrument	72
Cold Air Controls	47
Cold Weather Operation	76-78
Command Radio AN/ARC-3	51
Command Radio Operation AN/ARC-3	51
Communications Equipment Table	49
Communications & Radio Equipment	51
Compass — Radio AN/ARN-7	51
Control Pressure	61
Controls — Brake System	20-21
— Cabin Door	24
— Cold Air	47
— Communications & Radio Equipment	51
— Engine Fire Extinguisher	22
— Exterior Lighting	52-53
— Flight	16-18
— Flight Control System	16
— Heating & Ducting	47
— Interior Lighting	52
— Landing Gear System	18-20
— Pitot Heat Switches	51
— Propeller Anti-icing	48
— Radio Control Panel Lighting	52



— Vacuum	16
— Windshield Wipers	53
— Wing & Tail De-icing	51
Coolers — Oil Coolers & Shutter Levers	4
Correction — Airspeed Position	82
Cowl Flap Handles	2
Crew — Minimum Crew	55
Crew Duties (Not Applicable)	69
Cross Feed Handle — Suction	9
Cross Feed — Suction	68
Cruise — Instrument Cruise	73
Curve — Take-Off	94B
Cylinder Head Temperature Gage	3

## D

Data Case	53
Data — Operating	79
Deflated Tire Landings	43
Defrosting	47
De-icer — Wing & Tail	75
De-icers — Wing & Tail Control	50
De-icing & Anti-icing System	48
Descent — Checks & Operation	32
Descent — Instrument Flight	73
Desert Procedures	78
Description — Aircraft	1-24
Description & Operation of Auxiliary Equipment	47-54
Diagrams — Electrical System	14
— Emergency Equipment	21
— Emergency Equipment	38
— Exterior Inspection	26
— Fuel System	12
— G. C. A. Letdown	74
— General Arrangements	4
— Landing Pattern	34
— Landing Pattern One Engine	40
— Radio Range Letdown	73
— Servicing	23
Dilution — Oil	6
Distribution of Load	58
Ditching	44
Dome Light Switches — Cabin	52
Door — Cabin (Emergency Release Handle)	24
Drainage — Fuel Sump (Cold Weather)	78
Ducting & Heating	47
During Flight — Engine Failure	39
— Fire	42
During Take-Off Engine Failure	39
Duties — Crew (Not Applicable)	69

## E

Emergency — Climb	94L
— Single Engine Climb	94M
— Electrical Power System	45
— Entrance	44
— Equipment	22
— Equipment Diagram	38

— Flap System	45
— Fuel System	44
— Hand Crank (Flaps)	18
— Hand Crank (Landing Gear)	20
— Landing Gear Clutch	20
— Landing Gear Lever Release	19
— Landing Gear System	45
— Landings	43-44
— Procedures	37-45
— Release (Cabin Door & Escape Hatch)	24
— Service Ceiling	94N
Electrical — Fire	42
— Load Analysis Charts	64
— Power System Emergency	45
— Power Supply System & Indicators	10-13
— System Diagram	14
— System Limits	55
— System Operation	68
Elevator Controls & Indicators	16-18
Elimination — Smoke	42
Endurance — Maximum	94F
Engines	1
— Cold Weather Stopping	77
— Failure & Operation	37-41
— Fire (Ground & In-Flight)	41-42
— Fuel Controls & Indicators	8-9
— Gage Units	3
— Ground Operation & Tests	29-30
— In-Flight Operation	31-35
— Instruments	3
— Limitations	55
— Post-Flight Operation & Checks	36
— Selector Switch (Starting)	2
— Single Engine Climb	94D
— Starting	28
Entrance — Emergency	44
Equipment — Description & Operation of Auxiliary Equipment	47-54
— Emergency Equipment Diagram	38
— Miscellaneous	53
— Radio & Navigation	73
— Relief	54
— Table (Communications)	49
Explanation of Weight Limitations Chart	60
Exterior Inspection	25
Exterior Lighting	53
Extinguishers & Controls — Fire	22

## F

Failure — Engine	37
— Engine Failure Procedures	37-41
— Propeller	41
Feathering Buttons — Propellers	3
Feathering — Propeller	3
Filter Switches — Radio Range	51
Fire — Electrical Fire in Flight	42
— Engine Fire in Flight	42



— Engine Fire on the Ground .....	41
— Extinguisher Controls & Indicators .....	22
— Extinguisher (Engine) .....	22
— Extinguisher (Hand) .....	22
— Fuselage Fire in Flight .....	42
— Wing Fire in Flight .....	42
First Aid Kits .....	24
Flap Lever — Wing .....	18
Flaps — Cowl Flap Handles .....	2
— Position Indicator .....	18
— System Emergency .....	45
— Wing .....	18
Flight — Characteristics .....	61-62
— Checks (Pre-Flight) .....	25-30
(In-Flight) .....	31-35
(Post-Flight) .....	36
(Night-Additional) .....	28
— Cold Weather Operation .....	76-78
— Control System .....	16-18
— Desert Procedures .....	78
— Instrument Flight Operation .....	71-75
— Instrument Flight Radio & Navigation Equipment .....	73
— Report Case .....	54
— Turbulence & Thunderstorms .....	75
Fuel Booster Pump Switches .....	9
Fuel Flow Per Engine .....	92-94A
Fuel — Nautical Miles Per Engine .....	88-91
Fuel Pressure Drop Engine Operating .....	39
Fuel Quantity Data Chart .....	13
Fuel Selector Handles — Engine .....	8
Fuel System .....	6
— Booster Pumps (Operation) .....	63
— Diagram .....	12
— Emergencies .....	44
— Indicators .....	9
Fuel Tank Sequence .....	63

**G**

Gage — Carburetor Air Temperature .....	3
— Fuel System Indicators .....	9
— Instruments (Pitot & Static) .....	21-22
— Loadmeters .....	11
— Manifold Pressure .....	3
— Tab Position Indicators .....	17-18
— Tachometer .....	3
— Units (Engine) .....	3
— Vacuum Indicators .....	16
G. C. A. Letdown & Diagram .....	74
Gear — Landing Gear System,	
Controls & Indicators .....	18-20
— Landing Gear System Emergencies .....	45
— Limitations .....	60
Generators .....	10
— Inoperative Lights .....	11
— Loadmeters .....	11
— Switches .....	11
Glide — Maximum Glide Chart .....	46

Go Around	35
Go Around — Single Engine	41
Ground Fire	41

## H

Hand Crank — Emergency Flap Operation	18
— Emergency Gear Operation	20
Hand Fire Extinguisher	22
Handles — Cowl Flap	1
— Emergency Cabin Door Release	24
— Emergency Escape Hatch Release	24
— Engine Fuel Selector	8
— Parking Brake	21
— Suction Cross Feed	9
Harness — Shoulder	24
Head Temperature Gage — Cylinder	3
Heat — Cabin Heat Buttons	47
— Carburetor Anti-icing	75
— Levers (Manifold)	1
— Pilot Compartment Outlet Shut-Off	47
— Pitot Heater, Switches & Operation	51
Heating & Ducting & Windshield Defrosting	47
High Weight Landing	35
Holding — Instrument Flight	73

1

Ice, Snow & Rain .....	74
Icing — Anti-icing & De-icing Equipment .....	
Controls & Operation .....	47-51
— Carburetor Anti-icing .....	75
— Pitot Anti-icing .....	51
— Propeller Anti-icing .....	48
— Windshield Defrosting .....	47
— Wing & Tail De-icer .....	75
— Wing & Tail De-icing .....	50
Ignition Booster Switch .....	3
Ignition Switches .....	2
Indicators — Aileron & Rudder .....	17
— Elevator .....	18
— Engine .....	3
— Engine .....	56-57
— Engine Fire Extinguisher .....	22
— Flap Position .....	18
— Flight Tab Position .....	17
— Fuel System .....	9
— Generator Inoperative Lights .....	11
— Instruments .....	21
— Landing Gear Position .....	20
— Marker Beacon Receiver .....	
R-122/ARN-12 .....	51
— Radio Compass AN/ARN-7 .....	51
— Vacuum System .....	16
In Flight — Cold Weather Operation .....	77
— Electrical Fire .....	42
— Engine Failure .....	39
— Engine Fire .....	42
— Fuselage Fire .....	42
— Operational Instruction Charts .....	82-93

— Propeller Failure	41
— Restarting Engine	39
— Turbulence & Thunderstorms	75
— Wing Fire	42
Inoperative Lights — Generators	11
Inspection — Before Exterior	25
— Before Leaving Aircraft	36
— Exterior	25
— Exterior Inspection Diagram	26
— Interior	27
— Night Flight (Additional)	28
Instructions — Taxiing	30
Instruments	21
— Engine	3
— Flap Position Indicators	18
— Fuel System	9
— Inverter	11
— Inverter Switch	13
— Landing Gear Position Indicators	20
— Lighting Control	53
— Markings	56
— Radio Compass AN/ARN-7	51
— Static & Pitot Pressure	22
Instrument Flight	71-74
— Approaches & Diagrams	73-74
— Climb	72
— Cruising Flight	73
— Descent	73
— Holding	73
— Radio & Navigation Equipment	73
— Take-Off	71
Interior Heating & Windshield Defrosting	47
Interior Lighting	52-53
Interphone RC-36	51
Interphone Selector Switch & Volume Control	51
Inverter — Instrument	11
Inverter — Instrument Inverter Switch	13

## J

## K

Kits — First Aid	24
Kits — Mooring	54

## L

Landing — After Landing Checks	36
— Before Leaving Aircraft Checks	36
— Characteristics	61
— Cold Weather	77
— Cross Wind	34
— Curve	94E
— Emergencies (Deflated Tires, Unprepared Runways & Wheels Up)	43-44
— High Weight	35
— Minimum Run	35

— Night	33
— Normal	35
— Pattern	34
— Pattern (One Engine)	40
— Single Engine	40
— With No Power	41
Landing Gear — Controls & Operation	18-20
— Emergency Clutch	20
— Emergency Hand Crank	20
— Lever	19
— Lever Emergency Release	19
— Limitations	60
— Malfunction Light	19
— Position Indicators	20
— System Emergency	45
— Tail Wheel Lock System & Control	20
— Warning Horn & Silencer	20
Landing Lights — Limits	55
— Switch	53
Lavatory & Baggage Compartment Lights	52
Leaning — Manual Leaning	63
Letdowns — G. C. A. Letdown & Diagram	74
— Radio Range Letdown & Diagram	73-74
Levers — Cowl Flaps	2
— Landing Gear	19
— Manifold Heat	1
— Mixture	1
— Oil Cooler Shutters	4
— Propeller	3
— Shoulder Harness Locking	24
— Throttle	1
— Wing Flap	18
Liaison Radio Selector Switch	51
Lighting — Control (Instruments)	53
— Equipment	52
— Exterior	53
— Interior	52
— Pilot's Compartment	52
— Radio Control Panel	52
Lights — Generator Inoperative	11
— Landing Gear Malfunction	19
— Landing Lights Limits	55
— Lavatory & Baggage Compartment	52
Light Switches — Cabin Dome	52
— Landing Lights	53
— Map Reading	52
— Navigation Lights	53
— Passing Light	53
— Radio Controls Spotlight Rheostat Switch	53
— Taxi Lights	53
— Utility Light	52
Limitations — Electrical System	55
— Engine	55
— Landing Gear	60
— Landing Lights	55
— Performance	60
— Operating	55-60
— Operating Weight	55

— Weight & Balance	55
— Weight Limitations Chart	59
— Wing	58
Load Analysis Charts — Electrical	64
Load Distribution	58
Load Factors & Margin of Safety	58
Loadmeters	11
Lock — Flight Control	16
Locking Lever — Shoulder Harness	24
Long Range Prediction Graphs	94G-94K

## M

Main Differences Table	2
Malfunction Light — Landing Gear	19
Maneuvers Prohibited	55
Manifold Heat Levers	1
Manifold Pressure Gage	3
Manual Leaning	63
Map Case	53
Map Reading Light & Switches	52
Margin of Safety & Load Factors	58
Marker Beacon Receiver	
R-122/ARN-12	51
Marker Beacon Receiver Indicator & Operation R-122/ARN-12	51
Markings — Instrument	56
Master Switch Bar	10
Maximum Endurance	94F
Maximum Glide Chart	46
Minimum Crew	55
Minimum Run Landing	35
Minimum Run Take-Off	32
Minimum Safe Single Engine Airspeed	37
Miscellaneous Equipment	53
Mixture — Carburetor Air Temperature Gage	3
Mixture Levers	1
Mooring Kit	54

## N

Nautical Miles Per Pound of Fuel Graphs	88-91
Navigation Lights Switch	53
Navigation & Radio Equipment (Instrument Flight)	73
Night Flight Check — Additional	28
Night Landing	35
No Power Available Landing	41
Normal Flight	32-33
— Landing	33
— Procedures	25-36
— Take-Off	31

## O

Oil Bypass Buttons	6
Oil Coolers	4
Oil Cooler Shutter Levers	4
Oil Dilution Switches	6
Oil System	3
One Engine Landing Pattern	40

Operating Data	79-93
Operating Limitations	55-60
Operating Weight	58
— Limitations	55
— Limitations Chart	59
Operation — All Weather	71-78
— Anti-icing & De-icing Equipment	74-75
— Cold Weather	76-78
Operation & Description of Emergency Equipment	47-54
Operation — Desert Procedures	78
— Electrical System	68
— Emergency Operations	37-45
— Engine Ground Operation	29
— Fuel System	63
— Instrument Flight	71-74
— Normal Operation	25-36
— Pitot Heat	51
— Propeller Anti-icing	48
— Radios	51-52
— Systems Operation	63-68
— Turbulence & Thunderstorms	75
Outlet Shut-Off — Pilots Compartment Air	47
Overvoltage Relay	11

## P

Panel — Radio Control Lighting	52
Panels — Audio Switch	51
Parking Brake Handle	21
Parking — Cold Weather	78
Passing Light Switch	53
Passenger Seats	54
Pattern — Landing	34
— Landing (One Engine)	40
Penetration — Turbulent Air Chart	72
Performance Limitations	60
Pilots Compartment — Air Outlet Shutoff	47
— Lighting	52
Pitot Heater Switches & Operation	51
Pitot & Static Pressure Source	22
Position Indicators — Flap	18
— Flight Tab	17-18
— Landing Gear	20
Post Flight Check	36
Power Change	63
Power — Electrical Supply System	10
Power — No Power Landing	41
Power Schedules	83-87
Power Switch — Pilots Turn & Bank	11
Power System Emergency — Electrical	45
Prediction Long Range	94G-94K
Pressure — Control Pressure	61
Pressure Drop Engines Operating Normally — Fuel	39
Pressure — Manifold Pressure Gage	3
Pressure Source — Pitot & Static	22
Procedures — All Weather	71-78
— Bail Out	44
— Cold Weather	76-78

— Crash Landing	41	Selector Switch & Volume Control Interphone	51
— Desert	78	Servicing Diagram	23
— Ditching	44	Shoulder Harness Locking Levers	24
— Emergency	37-45	Shutter Levers — Oil Coolers	4
— Fire	41-42	Silencer — Warning Horn	20
— Instrument Flight	71-73	Single Engine — Climb Curve	94D
— Landing Emergencies	43-44	— Emergency Climb	94M
— Let Down	73-74	— Go Around	41
— Normal Operating	25-36	— Landing	40
— Single Engine	38	— Procedures	38
— Systems Emergencies	44-45	— Safe Minimum Airspeed	37
— Turbulence & Thunderstorms	75	Smoke Elimination	42
Prohibited Maneuvers	55	Snow, Ice & Rain	74
Propellers	3	Source — Pitot & Static Pressure	22
— Anti-icing, Control & Operation	48	Space — Capacity	58
— Failure	41	Spins	61
— Feathering	3	Spotlight Rheostat — Radio Controls Light	53
— Feathering Buttons	3	Stability	61
— Icing	74	Stall Chart	62
— Levers	3	Stalls	61
Pumps — Fuel Booster	63	Starter Switch	3
— Fuel Booster Switches	9	Starting — Cold Weather	76
		— Engines	28
		— Engine Selector Switch	2
		— System	2
		Static & Pitot Pressure Source	22
		Stopping Engines	36
		— Before Stopping Engines	36
		— Cold Weather	77
		Suction Cross Feed	68
		Suction Cross Feed Handle	9
		Sump Drainage — Fuel (Cold Weather)	78
		Supply — Electrical Power System	10
		Switches — Battery	11
		— Cabin Dome Lights	52
		— Engine Starting Selector	2
		— Filter (Range)	51
		— Fuel Booster Pump	9
		— Generator	11
		— Ignition	2
		— Ignition Booster	3
		— Instrument Inverter	13
		— Landing Lights	53
		— Lavatory & Baggage	
		— Compartment Lights	52
		— Map Reading Lights	52
		— Master Bar	10
		— Navigation Lights	53
		— Oil Dilution	6
		— Passing Light	53
		— Pilots Turn & Bank Power	11
		— Pitot Heater	51
		— Primer	3
		— Starter	3
		— Selector & Volume Control	
		— (Interphone)	51
		— Taxi Lights	53
		— Utility Lights	52
		— Voltmeter	11
		Switch Panels — Audio	51

## Q

Quantity — Fuel Data Chart	13
----------------------------	----

## R

Radar Letdown & Diagram — G. C. A.	74
Radio & Communications Equipment	51
Radio Compass & Operation AN/ARN-7	51
Radio Control Panel Lighting	52
Radio Controls Spotlight Rheostat Switch	53
Radio & Navigation Equipment	
(Instrument Flight)	73
Radio Operation	51
Radio Range Letdown	74
Radio Range Letdown Diagram	73
Rain, Ice & Snow	74
Reading Light Switches — Map	52
Receiver Indicators	51
Relay — Overvoltage	11
Release — Cabin Door Emergency Handle	24
— Emergency Escape Hatch Handle	24
— Landing Gear Lever Emergency	19
Relief Equipment	54
Restarting Engine in Flight	39
R-122/ARN-12 Marker Beacon	
Receiver, Indicators & Operation	51
Rudder & Aileron Indicators	17
Runways — Landing on Unprepared Runways	43

## S

Safe Minimum Airspeed — Single Engine	37
Safety & Load Factors — Margin	58
Seats	24
Seats — Passenger	54
Selector Handles — Engine Fuel	8
Selector Switch — Engine Starting	2

Systems — Anti-icing & De-icing	48
— Brake	20
— Electrical Limits	55
— Electrical Power Supply	10
— Flight Control	16
— Fuel	6
— Fuel Indicators	9
— Interior Heating & Windshield Defrosting	47
— Landing Gear	18
— Oil	3
— Starting	2
— Tail Wheel Lock & Control	20
— Vacuum	16
— Ventilation	47
Systems Diagrams — Electrical	14
— Fuel	12
Systems Emergencies — Electrical Power	45
— Flap	45
— Fuel	44
— Landing Gear	45
Systems Operation	63-68
— Electrical	68
— Fuel	63

## T

Tab — Flight Controls	16
Tab — Position Indicators	17
Table — Communications Equipment	49
— Main Differences	2
Tachometer	3
Tail Wheel Lock System & Control	20
Tail & Wing De-icer	75
Tail & Wing De-icers	50
Take-Off — After	32
— Before	30
— Chart	83
— Climb Over Obstruction	32
— Cold Weather	77
— Cross Wind	31
— Curve	94B
— Desert	78
— Engine Failure	39
— Instrument	71
— Minimum Run	32
— Night	32
— Normal	31
Tank Sequence — Fuel	63
Taxiing — Cold Weather	77
— Instructions	30
Taxi Lights Switch	53
Temperature Gages — Carburetor Air	3
— Cylinder Head	3

Tests — Engine Ground	29
Throttle Levers	1
Tires Deflated Landings	43
Traffic & Pre-Traffic Pattern Checks	33
Turbulence & Thunderstorms Flight	75
Turbulent Air Penetration Chart	72
Turn & Bank — Pilots Power Switch	11

## U

Units — Engine Gage	3
Use of the Charts & Problem (Flight Operation Instructions)	80
Use of the Chart (Weight Limitations)	60
Utility Light Switches	52

## V

Vacuum System, Control & Indicators	16
Vent & Heat Diagram	48
Ventilation System	47
Voltage — Overvoltage Relay	11
Voltmeter Switch	11
Volume Control — Interphone	51

## W

Warning Horn — Landing Gear	20
— Silencer	20
Weather — All Weather Operation	71-78
— Cold Weather Operation	76-78
— Desert Operation	78
Weight & Balance Limitations	55
Weight — Distribution	58
— Gross	58
— Limitations	55
— Limitations Chart	59
— Operating	58
Wheels — Landing Gear System, Controls & Operation	18-20
Wheels — Landing With Deflated Tires	43
Wheels Up Landing	44
Wind — Crosswind Landing	34
— Take-Off	31
Windshield Defrosting System	47
Windshield Wipers	53
Wing Flaps & Lever	18
Wing Limitations	58
Wing & Tail De-icer	75
Wing & Tail De-icers	50
Wipers — Windshield	53

## X - Y - Z